



Installation Instructions

#2651 — 1972-1976 Woodgrain Shift Console Insert Cover w/ AC

Computer Die Cut for Clean Lines & Precise Fit. Self-Adhesive Back for Easy Installation!

Congratulations on purchasing a fine addition to your Corvette's interior. By following these simple instructions, you can be assured of an easy installation that will enhance the appearance of your console for years to come.

Important Notice: The following additional items will be necessary for a proper installation. 1. Clean Rags. 2. Mild solvent, such as rubbing alcohol.

1. Inspect the insert you have received to verify it is correct for your console. Consoles in cars without air conditioning have a slot cut out of each forward corner to accommodate vent control knobs. Consoles for cars with air conditioning do not have these slots.

2. If your console has the original insert, it will have to be removed.

3. Clean the console with a clean rag and rubbing alcohol to remove all dirt, grease or old adhesive. Allow the alcohol to evaporate completely.

4. Without removing the adhesive backing on your new insert, test fit the piece so you can see how it will have to be placed and aligned.

5. Remove the backing and, being careful not to touch the adhesive with your fingers, place the insert in position and press firmly into place. Press down on all areas of the insert to ensure good adhesive contact.

Auto Accessories of America also offers inserts for deluxe door panels to match your new console insert. These are available as #3017 from Auto Accessories of America or any Authorized Dealer.



100 Classic Car Drive, Reedsville, PA 17084

(877) 4AAAdirect - (877) 422-2347 • Fax: 717-667-3174

Email: customerservice@AAAdirect.com • www.AAAdirect.com

