



## Installation Instructions

### #4490 1968-1982 Knockoff Spinner Kit

Congratulations on purchasing one of the finest wheel accessories available. By following these instructions, you can be assured of a simple and trouble-free installation.

**Important notice:** The following additional items will be necessary to install your Knockoff Spinner Kit: *Jack, Lug Wrench & Jack Stands*

**1.** Inspect the Knockoff Spinner Kit you have received. It should contain the following: *4 Adapters, 4 Spinners, 16 Set Screws & 1 Hex Key Wrench*. If your kit does not contain the correct assortment of pieces, return it to the dealer where purchased for replacement.

**2.** Jack up the car according to the manufacturer's instructions. Use jack stands to support the vehicle. Never work under a car that is supported only by a jack.

**3.** Remove the lugnuts and take the wheel off the car.

**4.** Remove the factory center cap from the wheel.

**5.** Each Knockoff Spinner Kit adapter is held on to the wheel with 3 small set screws which are supplied. Insert these screws into the threaded holes located around the edge of the adapter. **START THE SCREWS FROM THE INSIDE OF THE ADAPTER.** Turn each screw until its point is flush with the outside surface of the adapter.

**6.** Insert the adapter into the center cap opening of the wheel. Make sure that the adapter seats firmly against the front of the wheel.

**7.** While holding the adapter in the center of the opening,

tighten the adapter set screws with the hex key wrench which is supplied. Tighten the screws until the wrench starts to flex.

**8.** Test the tightness of the adapter by twisting by hand. The adapter should not move when moderate pressure is applied.

**9.** Install the wheel back on the vehicle according to the manufacturer's instructions.

**10.** Each spinner is held onto the adapter with a large set screw, which is supplied. Insert this screw into the threaded hole behind one of the ears on the spinner. **START THIS SCREW FROM THE OUTSIDE OF THE SPINNER.** Turn the screw until its point is flush with the inside surface of the spinner.

**11.** Screw the spinner on to the adapter already mounted on the wheel and tighten securely.

**12.** To lock the spinner on to the adapter, tighten the set screw on the spinner with the supplied hex key wrench until the wrench starts to flex. Store the hex key wrench in your vehicle because the spinner will have to be removed in the event of a flat tire.

This completes the installation on one wheel. Repeat these procedures on the remaining wheels. Once all 4 Knockoff Spinners are installed on the vehicle, emblems can be installed on the spinner. Be sure the spinners are clean and free of any grease or dirt to allow proper adhesion of the emblems. The adapters can be painted with flat black enamel or lacquer to match the wheel center.

---

100 Classic Car Drive, Reedsville, PA 17084

(877) 4AAAdirect or (877) 422-2347 • Fax: 717-667-3174

Email: [customerservice@AAAdirect.com](mailto:customerservice@AAAdirect.com) • [www.AAAdirect.com](http://www.AAAdirect.com)

