



INSTALLATION TIPS 1963-1967 CORVETTE FRONT BUMPERS




C2 Front Bumper Install Tips


- 1. Begin installation with the front inner brackets which protrude from below the bumper cover
- 2. Some slight adjustment of brackets may be necessary
- 3. Only install each bolt by a few threads so you can adjust the fitment before final tightening
- 4. Remember to install the center bar before tightening any hardware
- 5. Tighten hardware from the center of the vehicle outwards, with the center bar being last. Torque values can be found on the attached AIM Sheet(s)
 - a. Front Inner Brackets
 - b. Front Outer Brackets
 - c. Front Outer Bolt (through fiberglass)
 - d. Center Bar





· CHEVEOLET MOTOR DEVISION, GARCH	9PC	DATE ST	-	CICCH HOUNE	AUTL	24	α	
	14	1 428-63 1	WAS	120395 WASHER	170662	DH	IC/	[
FRONT BUMPER	14	8.4.(5)	ZVIEW	MOVED TO SHT. AS		15	101	l
A	REF. A3		-		+	╂		
0 / 9 000	123							
DWGPREL 4-2 CS REF: Prol. AI L-SBOOS L-	72		_					
DATE AGL. J. / CI L- L- L-	XISPET				+	+	\square	





CHEVROLET MOTOR DIVISION, GAC+	UPC	DATE	5774	REVISION MICONS	AN/174.	De	œ	-
FRONT BUMPER	14							
8 19000	REF. AZ							
DWG 7-30 CS REFIECR 72065 L- DATE REL, 8-4 C/ L- L- L-	T SHEET IX					-		Ć
	210							

