



FBM350D - Installation Instructions

The NoviStretch™ FBM350D mask is secured using snap fasteners integrated into the design. This requires snap-head screws, supplied in the hardware kit, be installed on the car as described below.

The FBM350D is design for installation on all:
2008 - Present Dodge Challengers
2006 - Present Dodge Chargers
2005 - 2008 Dodge Magnums
2005 - Present Chrysler 300

Enclosed you will find:

- FBM350DMask
- Hardware Kit containing four (4) snap-head screw studs; four (4) J-Clips; one (1) adhesive-backed velcro strip
- Installation Instructions & Warranty Information
(Please read all information carefully.)

Tools Required:

- Short handle Philips screwdriver
- flat-blade screwdriver
- snips or sidecutters

Step 1

Clean the bumper and surfaces under the car and the fender wells thoroughly (*tar and grease remover is recommended*).

Step 2

Turn the front wheels to gain easier access to the fender liner mounting screws/pins.

Step 3 (Fig. 3.1, 3.2, 3.3, 3.4, 3.5, and 3.6)

Locate and remove the lower-most retaining pin at the edge of the bumper, inside the fender liner & the upper-most pin (approx. 9-11" above).

Note: pins may be of two types:

1) Male/Female push pins, which are removed by pulling out the male portion and then removing the whole assembly or 2) Pop-Rivet pins, which are removed by raising the edge with a flat-blade screwdriver and using cutters to remove the head and then pushing out the shaft or alternately using a drill to drill out the rivet.



After removing the retaining pins, install a J-clip (Nipple side is toward the front of the car) at each of the two holes in the bumper. [The J-clip is designed to go around the edge of the fiberglass bumper or inner liner and serves as the nut for the screw you will be installing. Reposition the fender liner aligning the holes in the liner with the holes in the bumper. Now install the two (2) snap-head screw studs. Repeat this step on the other side of the car.



(Instructions continue on other side)



Step 4 (Fig. 4.1)

Begin the installation by fastening the snaps on one end of the mask to the screws just installed on the edge of the bumper.



Step 5 (Fig. 5.1)

Stretch the mask across the front of the bumper and attach to the other side of the car.

Note: the tension in the mask is normal and important to the overall performance of the product

Step 6 (Fig. 6.1)

Open the hood and holding the top of the mask pull it up to the hood opening and secure the looped strap on each corner of the mask over the corresponding hood-stopper/bumper.



Step 7 (Fig. 7.1)

Pull the bottom edge of the mask down under the bumper. Note the position of the Velcro strip on the bottom/center of the mask. Mark this position on the car and install the mating piece of Velcro to the stretch or tightness desired, taking care to completely clean the mounting surface.

Caution: allow 24 hr. cure time before trying to remove the mask after it has been attached.



Surface Prep & Care Instructions

NoviStretch® covers are constructed from synthetic stretch fabric that will not chaff or damage the painted surface and have been designed to perform in all weather & road conditions.

It is **important** that the painted surface be clean prior to installation of the cover. Over time and use, dirt or dust, may work its way between the cover and the painted surface. Regular cleaning of both the

Surface Prep & Care Instructions (cont.)

cover & surface is **essential** to provide proper protection. Severe weather conditions or travel on off-road surfaces increase the recommended frequency for inspection and cleaning.

It is expected to see some cosmetic damage (small holes, thinning, fading or discoloration) to the mask over time & miles as it does its job. However, proper care will maximize product life.

Cleaning and Care Instructions

- The mask can be cleaned by rinsing in water to remove any dirt or debris then squeezing the water out and let air-dry. Wash (by hand) only as necessary.
- Use a concentrated soap solution on areas of the mask that may be particularly dirty.
- For the best life do not leave the mask on the car while parked in the sun for extended periods.
- Avoid obstacles and low clearance areas in the roadway that may come in contact with the bottom of the car causing the mask to snag and the material to tear.

Notice: Patent Pending; NoviStretch™ Copyright © 2016 Novigo Designs, LLC. All Rights Reserved.

NOVIGO DESIGNS™ TWELVE (12) MONTH LIMITED WARRANTY

Novigo Designs, LLC warrants this product against "defects in material and workmanship" for a period of twelve (12) months from the original date of purchase by the original consumer purchaser. For full details and explanation of warranty coverage, requirements and policy – please go to the "Support" section of www.NoviStretch.com. Novigo Designs (and its authorized distributors) liability is limited to the materials and workmanship of the product. Novigo Designs is not responsible for damage caused by the product to the paint or finish of the vehicle. To avoid any possible damage and to get the maximum benefit from your Novigo Designs product, carefully follow the installation and care instructions provided. Novigo Designs, LLC.