



Installation Instructions

Vinyl Decals

NOTE: Some installations may require a heat gun/hairedryer to help contour the vinyl around compound curves on the vehicle.



Tools Required

- | | |
|---|------------------------------------|
| 1. Rubbing Alcohol or Alcohol Wipe | 3. Squeegee |
| 2. Spray Bottle w/ Water and Small Amount of Dish Detergent | 4. Microfiber Cloth/Rag (optional) |
| | 5. Straight Pin |

SURFACE PREPARATION

Using rubbing alcohol on a cloth or an alcohol wipe, thoroughly clean the installation area.

NOTE: Do not use household cleaners as they may interfere with adhesion.

INSTALLATION

1. Spritz installation area with water/soap mixture. This will allow the Vinyl/Lamin-x decal to move without adhesion prior to final placement.
2. Align the decal in the desired area and begin to pull off only one side of the vinyl from the backing paper.
3. Slowly apply the sticky side to the desired area using either a squeegee or a credit card covered with a microfiber cloth. Continue to peel the decal from the backing paper while progressively pushing out the bubbles with your squeegee until the entire decal is successfully applied.
4. If any bubbles still exist, you can use a straight pin to gently poke a hole in the bubble and work the area with your fingers to press it out.
5. Remove transfer paper. (**NOTE:** Not all Vinyl Decals will have a transfer paper)
6. Allow the adhesive to cure for 7 days before washing or waxing.



Scan the code for our
vinyl installation video.

100 Classic Car Drive, Reedsville, PA 17084

(877) 4AAAdirect or (877) 422-2347 • Fax: 717-667-3174

Email: customerservice@AAAdirect.com • www.AAAdirect.com

