



Installation Instructions

#X2525 1975-1979 Outside Mirror, RH



Tools Required

- | | | |
|-------------------------------|-------------------------|---------------------|
| 1. Hammer | 3. Center Punch | 5. Drill |
| 2. Drill Bits - 1/8" and 3/8" | 4. Phillips Screwdriver | 6. 5/32" Hex Wrench |

NOTE: Included with the Outside Mirror Kit is an improved mounting bracket and retaining screw. These components are packaged separately and are identified with an RH label on the package.

CAUTION: Always wear proper eye protection and gloves when hammering & drilling.

Prepare Parts: Using a 5/32" hex wrench, unscrew the existing bracket screw from the base of the new mirror, remove the screw and bracket, and discard bracket and screw.

NOTE: The removed bracket and screw will not be re-used.

1. Using the provided template, position the provided template onto the righthand (passenger) door and secure in place using painter's tape or similar tape.

2. Using a center punch and hammer, carefully punch mark two (2) screw locations to be drilled. Drill the punch mark locations with a 1/8" drill bit, then step up to a 3/8" drill bit.

3. Position the provided plastic gasket over the drill holes and install the two (2) expanding blind nuts. Secure the NEW mounting bracket to the door using the two (2) machine screws provided.

4. Secure the mirror onto the bracket with the NEW retaining screw using a 5/32" hex wrench.



100 Classic Car Drive, Reedsville, PA 17084
(877) 4AAAdirect or (877) 422-2347 • Fax: 717-667-3174

Email: customerservice@AAAdirect.com • www.AAAdirect.com

